Service: 604 -856- 9155

Email: service@natg.ca





Table of Contents

Phone Outline	3
Phone System Programming	4
Changing the name of a Phone	4
Programming One-Touch Keys with Features	4
Clearing Message Waiting Light	4
Programming System Speed Dials	4
Changing Internal Dialing from Voice/Ring	4
Activating Background Music	5
Changing Date and Time:	5
Voicemail Programming	6
Record Company Greetings	6
Holiday Greeting Activation/De-Activation	7
Making Changes to a Mailboxes	7

IMPORTANT NOTE:

The extension and mailbox numbers referenced in this guide are the most commonly used configuration. It does **not** guarantee that your company will use the same extension and mailbox numbers due to each systems **customized** configuration. If you are **unsure** of what numbers were used in your configuration, please call or email the NATG service department.



Phone Outline



•	Exit	Exit's out of various programming
	Security	Locks the phone for security purposes (IP Phones only)
	Message Indicator	Flashes when you have a voicemail (or a message waiting)
	Soft Keys	Corresponds with what the display says
	Help	Tells how a one touch key is programmed
•	One Touch Keys	Programmable buttons for features, lines, int/ext numbers
•	Recall	Transfers callers to an external number (if applicable)
•	Feature	Used for programming
•	Answer	Answers the First incoming call to a specific phone
•	Mic	Mutes the microphone while on speakerphone
•	Menu	Access to Company Directory, Call History and Ring Settings
•	Directory	
•	Up	_Adjusts the volume on the ringer, handset and speaker
•	Down	Adjusts the volume on the ringer, handset and speaker
•	Redial	Review the last numbers dialed
•	Speaker	Speakerphone
•	Transfer	Transfers a call to another extension or external number
•	Hold	Places the current call on hold



Phone System Programming

Changing the name of a Phone

- 1. Press Speaker key, dial 700
- 2. Enter the Extension number
- 3. Spell out name; press HOLD (NOTE: # moves cursor to right: FEATURE key moves cursor to left)
- 4. Press SPEAKER key

<u>Programming One-Touch Keys</u> <u>with Features</u>

From the employee's phone

- 1. Press Speaker key, dial 751
- 2. Press key you'd like to program
- 3. Enter 2 digit code
- 4. Press Speaker key

	Code	Feature	Brief Description
$\overline{}$	00	Not Defined	Clears the button and leaves it blank
П	01	DSS/One Touch	Extension number or a phone number
	03	DND Key	Sends calls directly to voicemail
	05	Headset	Needed if you are using a corded headset
$\Big $	10	Call Fwd	Forwards all calls immediately to desired destination
	37	DND Override	Access to a phone in DND or Call Fwd
П	78	Record	Records conversation into a mailbox
	. 84	Drop/Release key	Press this key to quickly drop an active call

Clearing Message Waiting Light

Message Waiting is often activated by accident. When calling an employee, you have an option to press the MW (message waiting) soft key (on display). This feature activates their message light and prompts them on the display to call you back but also can mislead you to think you have a voicemail. If an employee contacts you saying their message light is on but they do not have voicemail, follow these instructions to cancel it: **From the employee's phone that is flashing:**

- 1. Press Speaker key, dial 773
- 2. Press Speaker key

Programming System Speed Dials

- 1. Press Speaker key, dial 753
- 2. Enter a speed dial code: 000-999
- 3. Enter the desired Phone Number (with no 9 in front of it)
- 4. Press Hold key
- 5. **SPELL** out the **NAME** using the dial pad (**NOTE**: press # to move cursor to right or **FEATURE** key to move cursor to left)
- 6. Press Hold key
- 7. Press Speaker key

<u>To Delete</u>: Follow steps 1-3, then press exit soft key(top left key just under the display)

Changing Internal Dialing from Voice/Ring

When calling an employee's extensions you can set the phone to either ring so the employee will have to pick it up(or speaker) or to voice so your voice pages through the **speaker** of their phone. Here are the instructions on how to change that per phone: **From the employee's phone that you would like to change:**

- 1. Press **SPEAKER** key
- 2. Dial 721 for VOICE calls or 723 for RING tone
- 3. Press Speaker key



Activating Background Music

- 1. Press Speaker key
- 2. Dial **725**
- 3. Press Speaker key

To De-Activate: Press SPEAKER key, Dial 725

Changing Date and Time:

- 1. Press Speaker key
- 2. Dial **728**
- 3. Enter 2 DIGIT HOUR(in 24hr time) and 2 DIGIT MINUTE
- 4. Press SPEAKER key



Voicemail Programming

Record Company Greetings

- 1. From Extension (usually reception), press MESSAGE KEY
- 2. Press 72 to enter system administration
- 3. Press 4 to record an instruction greeting
- 4. Enter the greeting Mailbox you'd like to record:
 - a. **001** to record the **D**AY greeting
 - b. **<u>002</u>** to record the **NIGHT** greeting
 - c. 003 to record the Holiday greeting
 - d. 004 to record the COMPANY DIRECTORY Greeting
 - e. 005 to record the GENERAL INFORMATION Greeting
- 5. Press 7 to record and follow the prompts
- 6. Press 5 to listen to your recording and press # to exit listen mode
- 7. Press # to back up one step to step 3 to record another greeting
- 8. Hang up when you are finished

EXAMPLE:

<u>Mailbox</u>	<u>001</u> : ((DAY)
----------------	----------------	-------

- · Thank you for calling _____
- · If you know the extension of the person you are calling, please enter it now.
- For our Company Directory, press 2 (Goes to Mailbox 004)
- For hours of operation and location, press 3 (Goes to Sub Menu 005)
- · To reach reception or leave a general message, please remain on the line or press 0.
- To repeat this message, press *
- · Thank you for calling _____

Mailbox 002: (NIGHT)

- Thank you for calling _____
- · We are currently closed. Our regular business hours are
- · If you know the extension of the person you are calling, please enter it now.
- · For our Company Directory, press 2 (Goes to Mailbox 004)
- · For hours of operation and location, press 3 (Goes to Sub Menu 005)
- · To leave a general message for reception, please remain on the line or press 0.
- · To repeat this message, press *
- · Thank you for calling _____

Mailbox 004: (COMPANY DIRECTORY)

•	For	, please press
		, please press
		, please press
	For	, please press
	To repeat this message, press	



in the end...it all comes down to service

Mailbox 005: (GENERAL INFORMATION)

•	Our regular	business	hours are	<u>, </u>	

- · We are located at _____
- · Our fax number is _____
- · Please visit us online at www ______
- To repeat this message, press *

Mailbox 003: (HOLIDAY)

- Thank you for calling ______. We are currently closed for the "Christmas" holiday and will re open______.
- · If you know the extension of the person you are calling please enter it now.
- For our Company Directory, press 2 (Goes to Mailbox 004)
- For hours of operation and location, press 3 (Goes to Sub Menu 005)
- · To leave a general message, please remain on the line or press 0.
- · To repeat this message, press *
- · Thank you for calling

Holiday Greeting Activation/De-Activation

- 1. Record a holiday greeting.. ((Mailbox 003) see page 5 for instructions)
- 2. From Extension (usually reception), press MESSAGE KEY
- 3. Press 72 for system administration
- 4. Press 6 for override
- 5. When asked for the table: enter 01
- 6. Press ON soft key on display
- 7. Press Speaker

To DE-ACTIVATE: Follow steps 2 - 5; at step 6, Press OFF soft key

Making Changes to a Mailboxes

- 1. From Extension (usually reception), press Message Key
- 2. Press 72 for system administration
- 3. Press 7 for subscriber mailbox maintenance
- 4. Enter the Mailbox Number you'd like to Change
- 5. Choose from one of the following options:
 - a. Press 32 to erase all messages in a mailbox
 - b. Press 34 to ERASE the GREETING in a mailbox
 - c. Press 36 to erase the recorded name for the mailbox
 - d. Press 7 to Delete the Security code for a mailbox
 - e. Press 6 to RECORD the NAME for a mailbox

